

RJ11>RJ45 Voice Kit-4 User Standard

Installation Guide



Plug ADSL filter into BT wall outlet to be shared



Into



Plug RJ11 end of RJ11 to RJ45 patch lead into filter



Plug quad adaptor into filter

Ensure patch lead bends down



Plug BT end of BT to RJ45 patch leads into quad adaptor



Plug RJ45 end of BT to RJ45 patch leads into ports to be converted to voice



Plug RJ45>BT converters into corresponding wall outlets



Plug RJ45 end of RJ11 to RJ45 patch lead into port to be converted to ADSL



Plug RJ45>RJ11 converter into corresponding wall outlet

Telephone equipment uses what is known as a REN rating, the sum of all equipment connected MUST NOT exceed 4. Check equipment being connected to obtain the REN rating

run-IT-direct assumes no responsibility for damage caused by not adhering to these instructions

© 2008 run-IT-direct