

BT>RJ45 Voice Kit (Privacy Version)

Kit Contents



Fig 1 BT Privacy Quad Adaptor (1)



Fig 2 BT>RJ45 Converters (4)



Fig 3 BT>RJ45 Patch Leads (4)

- (1) Plug BT Privacy Quad Adaptor into the BT socket to be shared (Fig 1)
- (2) Plug the 4 Patch leads (Fig 3) into the Privacy Quad adaptor, The WHITE connector plugs into the Quad Adaptor.
- (3) Plug the RJ45 Ends (Grey/Clear) of the patch leads into the patch panel ports that you wish to convert to Voice.
- (4) Ensure that the corresponding wall outlets have the BT>RJ45 converters plugged in (Fig 2). **DO NOT CONNECT ANY DATA LEADS (COMPUTERS, PRINTERS ETC) TO OUTLETS PATCHED FOR VOICE!**

(Eg, Patch Panel Port 1 is patched for voice, ensure floor/wall outlet Port 1 has BT>RJ45 converter (fig 2) plugged in)

- (5) Connect equipment as required.

NOTES

Telephone equipment uses what is known as a REN rating, the sum of all equipment connected MUST NOT exceed 4. Check equipment being connected to obtain the REN rating

The Privacy version means no one can pick up on a call already in use, the LED's on the Privacy adaptor indicate a call is already in use (Incoming or outgoing) and on which port

run-IT-direct assumes no responsibility for damage caused by not adhering to these instructions

BT>RJ45 Voice Kit (Privacy Version)

Quick Setup Guide

Plug Privacy Quad Adaptor Into BT Wall Outlet To Be Shared



Plug 4 x Patch Leads Into Quad Adaptor



Into



=



Plug RJ45 Ends Of Patch Leads Into Desired Patch Panel Ports



Plug RJ45>BT Converters Into Corresponding Wall Outlets



Plug Equipment In As Desired



NOTES

Telephone equipment uses what is known as a REN rating, the sum of all equipment connected MUST NOT exceed 4. Check equipment being connected to obtain the REN rating

run-IT-direct assumes no responsibility for damage caused by not adhering to these instructions