

BT>RJ45 Voice Kit

Kit Contents



Fig 1 BT Quad Adaptor (1)



Fig 2 BT>RJ45 Converters (4)



Fig 3 BT>RJ45 Patch Leads (4)

- (1) Plug BT Quad Adaptor into the BT socket to be shared (Fig 1)
- (2) Plug the 4 Patch leads (Fig 3) into the Quad adaptor, The WHITE connector plugs into the Quad Adaptor.
- (3) Plug the RJ45 Ends (Grey/Clear) of the patch leads into the patch panel ports that you wish to convert to Voice.
- (4) Ensure that the corresponding wall outlets have the BT>RJ45 converters plugged in (Fig 2). **DO NOT CONNECT ANY DATA LEADS (COMPUTERS, PRINTERS ETC) TO OUTLETS PATCHED FOR VOICE!**

(Eg, Patch Panel Port 1 is patched for voice, ensure floor/wall outlet Port 1 has BT>RJ45 converter (fig 2) plugged in)

- (5) Connect equipment as required.

NOTES

Telephone equipment uses what is known as a REN rating, the sum of all equipment connected MUST NOT exceed 4. Check equipment being connected to obtain the REN rating

run-IT-direct assumes no responsibility for damage caused by not adhering to these instructions

BT>RJ45 Voice Kit

Quick Setup Guide

Plug Quad Adaptor Into BT Wall Outlet To Be Shared



Plug 4 x Patch Leads Into Quad Adaptor



Into



=



Plug RJ45 Ends Of Patch Leads Into Desired Patch Panel Ports



Plug RJ45>BT Converters Into Corresponding Wall Outlets



Plug Equipment In As Desired



NOTES

Telephone equipment uses what is known as a REN rating, the sum of all equipment connected MUST NOT exceed 4. Check equipment being connected to obtain the REN rating

run-IT-direct assumes no responsibility for damage caused by not adhering to these instructions